



NOTE 1 - White wire is connected to battery positive, or preferably, battery positive on ignition coil input.

NOTE 2 - Use engine block or negative battery post for ground point for black wire. When grounding to engine be sure that heavy gauge wire is used to ground engine block to negative battery post. Use supplied 12AWG wire to supplement your existing ground (negative battery terminal to engine) for best results.

**NEXT
IGNITION
CONDENSOR**

MISSION IGNITION SYSTEMS

Revision B